

Instructions for use – Quick Guide

Installation to be carried out by a Licenced Plumber in accordance with AS/NZS 3500.

Manufactured to AS3688-2005

For use with copper tube complying with AS1432-2004



1. Cut the tube squarely.
2. Deburr tube carefully, inside and out.
3. Check the seal is fitted firmly and is not damaged.
4. Insert the fitting until it hits the stop and mark the tube with a marker.
5. Ensure the tube is fully engaged and is sitting square.
5. Fit appropriate size jaws to the press tool. Press
6. Check the joint.

Note: If retrofitting, copper tube must be in good condition. Our fittings are compatible with other copper press fit systems manufactured to AS3688-2005 and approved press tools.